



Wind deflectors from ClimAir

- 1892 ML-Class W163, front windows, set of 2
- 2587 ML-Class W163, rear windows, set of 2



Stainless steel B-pillar covers

Material: high-gloss polished stainless steel!
 Installation: 3M double adhesive strip technique

- 6744163 B-pillar covers, set of 6



Fendertrims

Installation: The fendertrims can be clipped (without drilling) or fixed with screws, as required.
 Extent of delivery: 4 fendertrims with rubber edging and fixing material.

- 1631011 chrome-plated, set of 4
- 1631012 high gloss stainless-steel, set of 4





U Chrome exhaust tail pipe

This exhaust tail pipe comes ready with a screw attachment. No cutting out or changes to the bumper needed! Suitable for all models. Pipe diameter: 108 x 69 mm (oval)

- 1633051** chrome exhaust tail pipe, pc.
(can not be fitted to models with a spare wheel mount)



Stainless steel footrest

- 9988444** footrest with nonslip rubber insert. Simple to fit, pc.



Chrome outside mirror frames

Real chrome! Installation: 3M double adhesive strip technique

- 1633311** chrome outside mirror frames, for models up to 08/01, set of 2
1633313 chrome outside mirror frames, for models from 09/01 (model 2002), set of 2

Chrome boot lid handle cover

Real chrome! Installation: 3M double adhesive strip technique
No need to remove the original boot lid handle.

- 1633050** chrome boot lid handle cover, pc.
1633055 chrome boot lid handle cover, USA/Japan-version, pc.



Chrome side indicator frames

Real chrome! Installation: 3M double adhesive strip technique

- 1631015** chrome side indicator frames, for models up to 08/01, set of 2





Chrome headlight frames

Real chrome!
Installation: 3M double adhesive strip technique

- 1631000** chrome headlight frames, for models up to 08/01, set of 2
- 1632222** chrome headlight frames, for models from 09/01 (model 2002), set of 2



Chrome taillight frames

Real chrome! Installation: 3M double adhesive strip technique

- 8163049** chrome taillight frames, set of 2

Chrome fog light frames

Real chrome! Installation: 3M double adhesive strip technique

- 1631166** chrome fog light frames, for models from 09/01 (model 2002), set of 2



Chrome door handle covers

Real chrome! Installation: 3M double adhesive strip technique

- 8163036** chrome door handle covers for all 4 doors, set of 8



Chrome door handle shells

Real chrome! Installation: 3M double adhesive strip technique

- 3712000** chrome door handle shells, set of 4



Instrument cluster frame

Hand veneered!
Only the front frame has to be changed.

1633001 burl walnut wood, pc.

“avantgarde”

“wood”



Shift knobs

- 8857202** burl walnut wood/chrome “avantgarde”, automatic, pc.
- 8857220** burl walnut wood/chrome “avantgarde”, mechanical, pc.
- 1726602** burl walnut wood, automatic, pc.
- 1726502** burl walnut wood, mechanical, pc.

Note: The wood colours for precious wood parts vary considerably in the photographs, partly for photo technical reasons. We make an effort to supply you with a colour that matches your vehicle. Please note - wood is a natural product and you can not always avoid colour deviations.



Door handle insets

Hand veneered!
Simply exchange to the original door handle insets - clip fixing!

1633088 burl walnut wood, fit all models, set of 4

Chrome dashboard rings, up to 08/01

Real chrome!
Installation: 3M double adhesive strip technique

3001202 chrome dashboard rings for mod. up to 08/01, set of 3

Note: These chrome rings fit almost all MB models from 1984 with round dashboard switches (heating or air-conditioning).

Wood/chrome gear change gate sets

These sets consist of a wood or chrome frame and a matt chrome-plated gate. The wood versions include additionally the “avantgarde” shift knob in precious wood/chrome. Suitable for models with automatic gearbox.

- 1633012** burl walnut wood, for models up to 12/99, set of 3 (not illustrated)
- 1633017** burl walnut wood, for models from 01/00 (Tiptronic), set of 3
- 1631005** chrome, for models up to 12/99, set of 2
- 1633032** chrome, for models from 01/00 (Tiptronic), set of 2 (not illustrated)

Wood gear change gate frame

Hand veneered!
1633011 burl walnut wood (only frame), pc.



Wood centre console armrest cover

Hand veneered!

Installation: 3M double adhesive strip technique

1633005 up to chassis no. A289559 or X754619, pc.

1633007 from chassis no. A289560 or X754620, pc.



Wood/leather centre console armrest lid

Hand veneered!

The complete lid is to be changed.

163100701 burl walnut wood/black leather, up to chassis no. A289559 or X754619, pc.

163210701 burl walnut wood/black leather, from chassis no. A289560 or X754620, pc.

Other leather colours on request!



Chrome speedometer rings

Real chrome! Remove speedometer front housing and then insert rings.

8163017 chrome speedometer rings, set of 3



Chrome ventilation frames

Real chrome! Suitable for all ML W163 models! Installation: 3M double adhesive strip technique

8163023 chrome ventilation frames, front, fit all ML W163 models set of 3 (consists of: 1 left, 1 right and 1 centre ventilation frame)



商品明細			品番	税別価格	P
ML-Class W163					
サイドバイザー	2pcs	フロント用	1892	¥10,000	
		リア用	2587	¥8,000	
ステンレスピラーカバー	6pcs	ハイグロスステンレス	6744163	¥18,000	133
フェンダートリム	4pcs	クロームメッキ	1631011	¥29,000	
		ハイグロスステンレス	1631012	¥24,000	
クロームエキゾーストパイプ			1633051	¥29,000	
フットレスト		ステンレス	9988444	¥9,000	
クロームミラーフレーム	2pcs	~2001/8	1633311	¥17,000	
		2001/9~	1633313	¥17,000	134
クロームトランクリッドハンドルカバー			1633050	¥17,000	
		長さ620mm			
		USA/JAPAN仕様車用	1633055	¥9,000	
		長さ520mm			
クロームサイドマーカフレーム	2pcs	~2001/8	1631015	¥4,000	
クロームヘッドライトフレーム	2pcs	~2001/8	1631000	¥18,000	
		2001/9~	1632222	¥18,000	
クロームテールライトフレーム	2pcs		8163049	¥18,000	
クロームフォグランプフレーム	2pcs	2001/9~	1631166	¥20,000	135
クロームドアハンドルカバー	8pcs		8163036	¥16,000	
クロームドアハンドルシエル	4pcs		3712000	¥9,000	
スピードメーターフレーム		ウオールナット	1633001	¥46,000	
シフトノブ "アヴァンギャルド"		ウオールナット			
		AT車用	8857202	¥33,000	
		MT車用	8857220	¥33,000	
シフトノブ オールウッド		ウオールナット			
		AT車用	1726602	¥20,000	
		MT車用	1726502	¥20,000	
ドアハンドルインセット	4pcs	ウオールナット	1633088	¥99,000	
クロームエアコンダイヤルリング	3pcs	~2001/8	3001202	¥5,000	136
ギアチェンジゲートセット	3pcs	~1999/12	1633012	¥57,000	
		2001/1~ TIP車	1633017	¥57,000	
※ウオールナットシフトゲートフレーム+マットクロームシフトゲート+シフトノブ"アヴァンギャルド"のセットです					
クロームギアチェンジゲートセット	2pcs	~1999/12	1631005	¥22,000	
		2001/1~ TIP車	1633032	¥22,000	
※クロームシフトゲートフレーム+マットクロームシフトゲートのセットです					
シフトゲートフレーム		ウオールナット	1633011	¥27,000	
センターコンソールアームレストカバー		ウオールナット			
		~A289559 or X754619	1633005	¥29,000	
		A289560 or X754620~	1633007	¥29,000	
センターコンソールアームレスト(ASSY)		ウオールナット/ブラックレザー			
		~A289559 or X754619	163100701	¥99,000	137
		A289560 or X754620~	163210701	¥99,000	
クロームスピードメーターリング	3pcs		8163017	¥10,000	
クロームベンチレーションフレーム	3pcs	フロント	8163023	¥20,000	